



EXECUTION STATEMENT FOR INSTALLATION OF NATURAL STONE ON INTERNAL FLOOR BY ADHESIVE SLURRY METHOD

Substrate

Concrete slab to be covered with Natural stone using thick bed mortar shall be sound, clean and free of dirt, oil, grease, curing compounds etc.

Surface Preparation:

- a) Ensure the substrate is clean and free from impurities like dust, dirt, debris, oil, grease, curing agents, loose plaster etc.
- b) Dampen the wall before application of thin set adhesive
- c) Clean the back of tile for any dust or coating.

Mixing

A) Mixing proportions

a) Slurry bond coat :- Use Laticrete 290 thin set adhesive as slurry coat in place of neat cement slurry to provide stronger bond and better adhesion

20kg of Laticrete 290 mixed with approx 7-8 ltr of potable water will give an approximate coverage of 100 sft for a thickness of 1 – 1.5 mm.

b.) Semi Dry Mortar Bed:- Use a mix of Portland cement and dry concrete sand mixed with water as specified

Application

- a) Ensure that the substrate is clean to receive the mortar bed.
- b) Apply a slurry bond coat of Laticrete 290 mixed with water on the surface approx 1.5 mm thick before spreading the cement-sand mortar.
- c) Spread mortar bed level and plumb while the slurry bond coat is tacky.
- d) Spread slurry bond coat consisting of Laticrete 290 mixed with water approx 1.5 mm thick over the semi dry bed while it is fresh

e) Align tiles to show uniform joints and beat with a hard wood block or rubber.

f) Clean excess mortar from the tile surface with wet cloth or sponge while mortar is fresh.

Grouting:-

When the tiles have set firm, spacers and bottom support can be removed.

I Cement based colour Grout

Use Laticrete 600 series Unsanded Grout Filler (available in a range of colours) when grout joints are less than 3 mm wide and Laticrete 500 series Sanded Grout Filler (available in a range of colours) for joints 3mm – 12mm.

The Cement based colour joints are strong and are resistant to weather, cracking and discolouration.

Mixing Ratio:

Laticrete Unsanded grout : Latex 282

10kg bag : 3.75 ltr

Laticrete Sanded grout : Latex 282

10 kg bag : 1.75 ltr

Mix the grout filler with 282 Latex Admix , mix only as much can be used in ½ hour or less. Clean up immediately before beginning next mix.

When applying, the grout joints should be free of dirt, debris or tile spacers. Sponge or wipe dust/dirt of tile faces and remove water standing in joints. Pack joints full and free of voids with rubber grouting float. Remove excess grout from tile faces using edge of rubber float and diagonal strokes (at 45° angle to direction of joints). When the joints have set, use a moist sponge to remove excess grout from the tile and joint. Use minimal water for clean up. Final clean up to remove any grout haze should be carried out within the next 12-24 hours.

II Laticrete Latapoxy SP-100 – Stain free, chemical resistant epoxy grout

Latapoxy Sp-100 is a colour fast, non-staining epoxy grout highly suitable for high traffic areas. It is unaffected by most food and beverage spillages, cleaning chemicals, dilute acids and alkalies.

Mixing & Application

1 Before grouting, remove all dust & impurities from the tiles. Dampen the tiled surface with a sponge.

2 Pour the contents of Part A & Part B into a pail and mix together for 1 min.

3 Add the part C filler powder $\frac{3}{4}$ of the content and mix together. Add remaining filler powder if required to achieve desired consistenc

4. Fill the joints using a rubber float.
- 5 Remove the excess grout, holding the float diagonally.
- 6 After 30-45 min of the application of the grout, scrub the surface of the tile & joint with clean water and scrubber provided to remove any excess grout.
- 7 Draw a clean cloth and drag across the tile to remove any residue.
- 8 Next day clean the grout haze from the tile with clean water

Expansion & Control Joints

- a) Existing joints in the structure must be carried through to the surface of tile/stone flooring with same width as structural joint and shall conform to architectural details.
- b) Interior areas shall have expansion joints spaced at a maximum of 7m x 7m.
- c) Find attached Tile Council of America details EJ – 171 for expansion joints.

TECHNICAL SERVICES

NOTE: LATICRETE Method Statements are provided for information purposes. The LATICRETE Product Data sheets supercede any information provided in the method statement.

NOTE: LATICRETE Product datasheets are subject to change without notice. For latest revision, check our website at www.myklaticrete.com

“As a professional courtesy, LATICRETE offers technical services free of charge. LATICRETE does not have any expressed or implied contractual obligation or duty to provide those technical services.

The user maintains all responsibility for verifying the applicability and suitability of the technical service or information provided by LATICRETE representatives. Moreover, technical service visits and consultations do not constitute express or implied approval by LATICRETE of product use or other construction means or methods. By providing technical services, LATICRETE does not undertake to perform any duty owed by the user to any third party, and no third party should rely on LATICRETE providing technical services”

For additional technical support, contact Laticrete Technical Services Division.