



INSTALLATION OF NATURAL STONE ON GYPSUM WALL BOARD BY THINSET METHOD

- Existing substrate : Gypsum wall board
- New tiling : Natural Stone
- Laticrete Adhesive proposed : Laticrete 111 + Laticrete 4237
- Packing : L111- 20kg
L73 – 20 ltr
- Mixing ratio : 20kg bag L111: 5.5ltr L4237
- Coverage : Depends on the size of tile and thickness of adhesive applied

Tile Size	Adhesive thickness	Coverage
300x300mm	3mm	55-60 sft
450x450mm	4.5mm	35-40 sft
600x600mm	6 mm	25-30 sft
900x900mm	7.5mm	18-20 sft
> 900x900mm	9 mm	12-15 sft

- Laticrete grout proposed :
Option I : Laticrete tile grout with Laticrete 1776 grout admix plus
- Packing : L500/600 grout powder – 10kg
L1776 grout admix plus– 20 ltr
- Mixing ratio : 1 bag of 10kg of 600 series powder : 3.75 ltr of L1776 grout admix plus
1 bag of 10kg of 500 series powder : 1.75 ltr of L1776 grout admix plus
- Colours available : 43 colours
- Coverage : Depends on the tile size, joint depth and joint width
- Option II : Latapoxy SP100 Stainfree grout
- Packing : 5.5 kg
- Mixing ratio : Pre measured kit
- Colours available : 43 colours
- Coverage : Depends on the tile size, joint width and depth

